


Switchbox Installation Guide (SBM-225, SBM-425)


Instructions:

These diagrams show which cables you need to hook up different switchboxes to different printers.


2-1 Parallel




2-1 Serial



4-1 Parallel



4-1 Serial



Cable #	Length/Description	Part #
1	6' DB25 M/M 25 Conductor Cable	CIB-004-06
2	10' PC to Bi-Directional Printer Cable	CIB-25C-10
3	10' PC to Printer Cable	CIB-001-10
4	6' DB25 F/M HP Plotter/Laserjet Cable	CIB-035-10
5	DB9F - DB25M Null Modem/Printer Cable	CIB-036-10